

**EDIFIER****G10**

Gaming Headphones

7.1 Multi-channel Gaming Headphones

## Operating Instructions

**EDIFIER International Limited**  
www.edifier.com  
© 2017 Edifier International Limited. All rights reserved.  
Printed in China

**NOTICE:**  
For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.

Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

Ver1.0 IB-200-G00100-00

**Tips:** Before use the headphone, please carefully read this user manual and keep it for further reference.

**■Features**

- 40mm Neodymium drivers provide quality sound
- 7.1 Virtual surround sound, personalized mode supported by software for gaming immersion
- Leatherette ear pads filled with extra-thick foam
- Camouflage housing with a matte finish
- Rotating, unidirectional mic
- 2.5m cable with in-line remote and mute switch
- USB Virtual 7.1 Streaming Sound

**■Specifications**

Type: headset, moving coil  
Driver unit: 40mm  
Frequency response: 20Hz-20kHz  
Sound pressure level (SPL): 90dB  
Impedance: 32ohm  
Connector: USB plug  
Cable length: 2.5m

**■Box content**

1

**■Usage**

1. Connect the USB cable to device;



2. Adjust the headphone to a suitable position and wear on your head;




3. Base on yourself head size, adjust the bracket length to keep comfortable;



4. Base on your self requirement, follow the below operation to use the headphone.

2

**■Operational guide****■Installing steps of sound effect adjustment software**

1. Log in the website: <http://www.edifier.com/cn/zh/headphones/g10> to download the software package, find the "setup.exe" file, and start to install the EDIFIER software.

2. According to the guide to finish the software installation.



3

Tips: In installing process, there may be an anti-virus program with false warning and stop the installation program, lead to installation fail. So please close the anti-virus software before install this software, to guarantee the installation successful.



3. Installation completed, re-start the computer and use.



4. Start the gaming and finish setting based on your needs.



4

**■Main interface**

1. Function interface of speaker:  
21 channels, environment simulation sound effect, EQ adjustment and other strong function.



2. microphone function interface:  
Multi-settings of microphone sound effect.



5



1. To prevent possible hearing damage, do not listen at high volume levels for long periods.
2. Fully understand user manual before use.
3. Ensure your player at low volume levels or power off before you leaving.



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



For traffic safety, do not use earphones while driving or cycling.



The operation of switches on your hi-fi system or plugging in the earphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the earphones.



For traffic safety, do not use earphones while driving or cycling.



1. "To prevent possible hearing damage, do not listen at high volume levels for long periods."



2. "Fully understand user manual before use."



3. "Ensure your player at low volume levels or power off before you leaving."



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



For traffic safety, do not use earphones while driving or cycling.



Houd toezicht op kinderen tijdens het gebruik van het apparaat; dit product is geen speelgoed.



Luisteren met de koptelefoon op hoog volume – met name gedurende een langere periode – kan leiden tot schade aan uw gehoor.



De bediening van de schakelaars op uw hifisysteem of het insteken van uw koptelefoon kan leiden tot harde klikgeluiden wat uw gehoor kan aantasten.



Om deze reden dient de volumeknop altijd op een minimum te worden geschakeld, voordat er tussen de verschillende bronnen (tuner, draaitafel, cd-speler, enz.) wordt geschakeld of de koptelefoon wordt aangesloten.



Met het oog op verkeersveiligheid dient de koptelefoon niet te worden gebruikt tijdens het rijden of fietsen.



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



1. "Houd toezicht op kinderen tijdens het gebruik van het apparaat; dit product is geen speelgoed."



2. "Luisteren met de koptelefoon op hoog volume – met name gedurende een langere periode – kan leiden tot schade aan uw gehoor."



De bediening van de schakelaars op uw hifisysteem of het insteken van uw koptelefoon kan leiden tot harde klikgeluiden wat uw gehoor kan aantasten.



Om deze reden dient de volumeknop altijd op een minimum te worden geschakeld, voordat er tussen de verschillende bronnen (tuner, draaitafel, cd-speler, enz.) wordt geschakeld of de koptelefoon wordt aangesloten.



Met het oog op verkeersveiligheid dient de koptelefoon niet te worden gebruikt tijdens het rijden of fietsen.



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

**EN Warning!**

To guarantee your personal safety, please do not wear or keep earphones in the vicinity (closer than 10cm) of a pacemaker.

Do not insert plug into electric sockets.

Supervise children when using the equipment, the product is not a toy.

Earphone listening at high volume levels – particularly, over extended periods of time – may damage your hearing.

The operation of switches on your hi-fi system or plugging in the earphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the earphones.

For traffic safety, do not use earphones while driving or cycling.

1. "To prevent possible hearing damage, do not listen at high volume levels for long periods."

2. "Fully understand user manual before use."

3. "Ensure your player at low volume levels or power off before you leaving."

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

1. "To prevent possible hearing damage, do not listen at high volume levels for long periods."

2. "Fully understand user manual before use."

3. "Ensure your player at low volume levels or power off before you leaving."

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

1. "To prevent possible hearing damage, do not listen at high volume levels for long periods."

2. "Fully understand user manual before use."

3. "Ensure your player at low volume levels or power off before you leaving."

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

1. "To prevent possible hearing damage, do not listen at high volume levels for long periods."

2. "Fully understand user manual before use."

3. "Ensure your player at low volume levels or power off before you leaving."

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

1. "To prevent possible hearing damage, do not listen at high volume levels for long periods."

2. "Fully understand user manual before use."

3. "Ensure your player at low volume levels or power off before you leaving."

**CN 安全注意事項:**

為保護您的人身安全, 請勿將該耳機佩戴或放置在離心臟起搏器附近的位置(小於10CM)。

請勿將插頭插入電源插座。

兒童應在成人監督下使用本設備, 本產品並非玩具。

在高音量下使用耳機——特別是長時間使用——可能會對您的聽力造成損傷。

操作高保真音響開關或插入耳機時可能會發出尖利的聲音, 其在高音量設置下可能會影響您的聽力。因此, 在切換各種音源或插入耳機前, 請將音量控制設置為最低。

為交通安全起見, 駕駛時或騎自行車時請勿使用耳機。

Lorsque vous procédez à un réglage sur votre installation hi-fi ou que vous branchez le casque sur l'installation, des bruits dangereux pour l'oreille peuvent se produire si le son est réglé sur un volume élevé. Pour cette raison, il faut toujours mettre le son au minimum avant de passer d'une source à l'autre (radio, platine, lecteur de CD ...) ou de brancher le casque.

Pour ne pas mettre en danger votre sécurité au volant ni celle des autres usagers de la route, n'utilisez jamais le casque lorsque vous conduisez ou que vous roulez à vélo.

Un casque d'écoute utilisé à un volume élevé risque de provoquer de troubles de l'audition, en particulier s'il est porté de façon prolongée.

Lorsque vous procédez à un réglage sur votre installation hi-fi ou que vous branchez le casque sur l'installation, des bruits dangereux pour l'oreille peuvent se produire si le son est réglé sur un volume élevé. Pour cette raison, il faut toujours mettre le son au minimum avant de passer d'une source à l'autre (radio, platine, lecteur de CD ...) ou de brancher le casque.

Pour ne pas mettre en danger votre sécurité au volant ni celle des autres usagers de la route, n'utilisez jamais le casque lorsque vous conduisez ou que vous roulez à vélo.

Alors que vous conduisez, veillez à ne pas écouter de la musique à un volume trop élevé, surtout pendant de longs périodes – cela peut entraîner une dégradation de l'audition.

La utilitzación de auriculares a un volumen muy alto – sobre todo al utilizarlos durante largos períodos – puede conducir al deterioro del oido.

Al operar los interruptores de su sistema HiFi o al conectar los auriculares al sistema puede hacer clic, lo que a un volumen muy alto puede deteriorar el oido. Por lo tanto disminuya el nivel de volumen al mínimo al seleccionar entre diferentes fuentes (radio, tocadiscos, reproductor de CD ...) en su sistema HiFi o al conectar los auriculares.

Para no ponen en peligro ni su capacidad de conducir, ni la seguridad de otros usuarios de la vía pública, no utilice en ningún caso sus auriculares al conducir un vehículo o al andar en bicicleta.

La utilización de auriculares