

**NOTICE**  
For continued technical improvements and system upgrades,  
the information contained herein may be subject to  
change without prior notice.

Copyright ©2016  
Edifier, Inc.  
Manual Edition 1.4, Jan. 2016  
Printed in China



**M3200 Multimedia Speaker**  
User Manual  
Please read this manual carefully before operating the system.

**Edifier®**  
Edifier International Limited  
Made in China

Products manufactured by Edifier will be validated for a variety of applications. Features and functions shown in this manual  
may differ slightly from the actual product. Please refer to the actual product for details.

3 2 1 0

**Important Safety Instruction**

Please read this manual carefully before operating the system.

**CAUTION**  
WARNING

**Box content**

- 2 Satellite speakers (with cable)
- 1 Subwoofer
- 3.5mm to 3.5mm connector cable
- 1 User manual

**Safety Instructions**

Please read this manual carefully before operating the system.

1 2

**INSTRUCCIONES DE SEGURIDAD IMPORTANTES**

Antes de utilizar este producto, lea detenidamente el manual. Este manual contiene instrucciones importantes de seguridad y consejos de uso. No se permite copiar o traducir este manual sin el consentimiento escrito de Edifier.

**Contenu du coffret**

- 2 haut-parleurs satellites (avec câble)
- 1 Subwoofer
- Câble connecteur 3,5mm sur 3,5mm
- Manuel d'utilisateur

**CONSEILS DE SÉCURITÉ**

1 2

**INSTRUCCIONES DE SEGURIDAD IMPORTANTES**

Antes de utilizar este producto, lea detenidamente el manual. Este manual contiene instrucciones importantes de seguridad y consejos de uso. No se permite copiar o traducir este manual sin el consentimiento escrito de Edifier.

**Contenido de la caja**

- Subwoofer
- 2 altavoces satélite (con cable)
- 3.5 mm a 3.5 mm de cable conector
- 1 manual de usuario

**INSTRUCCIONES DE SEGURIDAD**

1 2

**WICHTIGE SICHERHEITSANWEISUNGEN**

Bitte lesen Sie dieses Handbuch vor dem Gebrauch des Produktes. Es enthält wichtige Sicherheitshinweise und Gebrauchsanweisungen. Bitte lesen Sie das Handbuch vor dem Gebrauch des Produktes.

**Packungsinhalt**

- Subwoofer
- 2 Satellitensprecher (mit Kabel)
- Verkabeler Controller
- 3,5 mm 3,5 mm Ausbinder
- Benutzeranleitung

**SICHERHEITSHINWEISE**

1 2

**IMPORTANTI ISTRUZIONI DI SICUREZZA**

Leggere attentamente il manuale di istruzioni prima di utilizzare il prodotto. Questo manuale contiene importanti avvertenze di sicurezza e istruzioni d'uso. È vietata la ristampa o la traduzione senza permesso scritto da Edifier.

**Contenido da confeeção**

- Subwoofer
- 2 altavozs satélite (com cabo)
- Cabo do conector 3,5 mm a 3,5 mm
- Manual do usuário

**ATENÇÃO**

1 2

**Wichtige Sicherheitsanweisungen**

Bitte lesen Sie dieses Handbuch vor dem Gebrauch des Produktes. Es enthält wichtige Sicherheitshinweise und Gebrauchsanweisungen. Bitte lesen Sie das Handbuch vor dem Gebrauch des Produktes.

**Packungsinhalt**

- Subwoofer
- 2 Satellitensprecher (mit Kabel)
- Verkabeler Controller
- 3,5 mm 3,5 mm Ausbinder
- Benutzeranleitung

**SICHERHEITSHINWEISE**

1 2

**Illustrations and Functional Diagram**

- Subwoofer
- Satellite speakers
- Wired controller
- Base adjustment
- PC - PC signal input
- CD - CD signal input
- Connector port for wired controller
- Port for the satellite speakers
- Power cord
- Power switch
- User's manual
- Audio connecting cable
- Master volume control
- Light blue as power indicator
- Headphone output
- 3.5mm stereo jack as AUX input
- Wired controller remote
- Wired controller base

1 2

**Illustrations and Functional Diagram**

- Subwoofer
- Satellite speakers
- Wired controller
- Base adjustment
- PC - PC signal input
- CD - CD signal input
- Connector port for wired controller
- Port for the satellite speakers
- Power cord
- Power switch
- User's manual
- Audio connecting cable
- Master volume control
- Light blue as power indicator
- Headphone output
- 3.5mm stereo jack as AUX input
- Wired controller remote
- Wired controller base

1 2

**Illustrations and Functional Diagram**

- Subwoofer
- Satellite speakers
- Wired controller
- Base adjustment
- PC - PC signal input
- CD - CD signal input
- Connector port for wired controller
- Port for the satellite speakers
- Power cord
- Power switch
- User's manual
- Audio connecting cable
- Master volume control
- Light blue as power indicator
- Headphone output
- 3.5mm stereo jack as AUX input
- Wired controller remote
- Wired controller base

1 2

**Illustrations and Functional Diagram**

- Subwoofer
- Satellite speakers
- Wired controller
- Base adjustment
- PC - PC signal input
- CD - CD signal input
- Connector port for wired controller
- Port for the satellite speakers
- Power cord
- Power switch
- User's manual
- Audio connecting cable
- Master volume control
- Light blue as power indicator
- Headphone output
- 3.5mm stereo jack as AUX input
- Wired controller remote
- Wired controller base

1 2

**Illustrations and Functional Diagram**

- Subwoofer
- Satellite speakers
- Wired controller
- Base adjustment
- PC - PC signal input
- CD - CD signal input
- Connector port for wired controller
- Port for the satellite speakers
- Power cord
- Power switch
- User's manual
- Audio connecting cable
- Master volume control
- Light blue as power indicator
- Headphone output
- 3.5mm stereo jack as AUX input
- Wired controller remote
- Wired controller base

1 2

**Illustrations and Functional Diagram**

- Subwoofer
- Satellite speakers
- Wired controller
- Base adjustment
- PC - PC signal input
- CD - CD signal input
- Connector port for wired controller
- Port for the satellite speakers
- Power cord
- Power switch
- User's manual
- Audio connecting cable
- Master volume control
- Light blue as power indicator
- Headphone output
- 3.5mm stereo jack as AUX input
- Wired controller remote
- Wired controller base

1 2

**Specification**

Power output: RMS 2 x 9W + 16W (THD <10%)

Frequency response: 20Hz - 20kHz

SNR: >90dB

Dynamic range: 110dB

Input impedance: 16K ohm

Speaker impedance: 8 ohm

Dimensions: 198 x 116 x 120 mm (L x W x H)

Weight: 1.8 kg

**Troubleshooting**

- No sound from speakers: Check connections, volume, power, and polarity.
- No sound from subwoofer: Check connections and volume.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.
- No sound from subwoofer: Check volume and connections.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.

1 2

**Specification**

Power output: RMS 2 x 9W + 16W (THD <10%)

Frequency response: 20Hz - 20kHz

SNR: >90dB

Dynamic range: 110dB

Input impedance: 16K ohm

Speaker impedance: 8 ohm

Dimensions: 198 x 116 x 120 mm (L x W x H)

Weight: 1.8 kg

**Troubleshooting**

- No sound from speakers: Check connections, volume, power, and polarity.
- No sound from subwoofer: Check connections and volume.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.
- No sound from subwoofer: Check volume and connections.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.

1 2

**Specification**

Power output: RMS 2 x 9W + 16W (THD <10%)

Frequency response: 20Hz - 20kHz

SNR: >90dB

Dynamic range: 110dB

Input impedance: 16K ohm

Speaker impedance: 8 ohm

Dimensions: 198 x 116 x 120 mm (L x W x H)

Weight: 1.8 kg

**Troubleshooting**

- No sound from speakers: Check connections, volume, power, and polarity.
- No sound from subwoofer: Check connections and volume.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.
- No sound from subwoofer: Check volume and connections.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.

1 2

**Specification**

Power output: RMS 2 x 9W + 16W (THD <10%)

Frequency response: 20Hz - 20kHz

SNR: >90dB

Dynamic range: 110dB

Input impedance: 16K ohm

Speaker impedance: 8 ohm

Dimensions: 198 x 116 x 120 mm (L x W x H)

Weight: 1.8 kg

**Troubleshooting**

- No sound from speakers: Check connections, volume, power, and polarity.
- No sound from subwoofer: Check connections and volume.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.
- No sound from subwoofer: Check volume and connections.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.

1 2

**Specification**

Power output: RMS 2 x 9W + 16W (THD <10%)

Frequency response: 20Hz - 20kHz

SNR: >90dB

Dynamic range: 110dB

Input impedance: 16K ohm

Speaker impedance: 8 ohm

Dimensions: 198 x 116 x 120 mm (L x W x H)

Weight: 1.8 kg

**Troubleshooting**

- No sound from speakers: Check connections, volume, power, and polarity.
- No sound from subwoofer: Check connections and volume.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.
- No sound from subwoofer: Check volume and connections.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.

1 2

**Specification**

Power output: RMS 2 x 9W + 16W (THD <10%)

Frequency response: 20Hz - 20kHz

SNR: >90dB

Dynamic range: 110dB

Input impedance: 16K ohm

Speaker impedance: 8 ohm

Dimensions: 198 x 116 x 120 mm (L x W x H)

Weight: 1.8 kg

**Troubleshooting**

- No sound from speakers: Check connections, volume, power, and polarity.
- No sound from subwoofer: Check connections and volume.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.
- No sound from subwoofer: Check volume and connections.
- No sound from one speaker: Check volume and connections.
- No sound from all speakers: Check power and connections.

1 2

Edifier®

Edifier®

Edifier®

Edifier®

Edifier®

Edifier®

Edifier®