

EDIFIER

W280BT
Bluetooth Stereo Headphones

Operating instructions

EDIFIER International Limited
www.edifier.com
© 2017 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.

Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

Ver1.0 IB-200-W280BT-01

Tips: before use this product, please carefully read this user manual and security keep it for further reference.

■Features

- In-ear sports headphones with simple and lightweight design for comfortable wear.
- With soft ear holder for stable wear and suitable for fitness, running and etc.
- NofeB unit produce strong low frequency and outstanding sound.
- CSR chip with Bluetooth V4.1 supports up to 10m wireless connection.
- Working time up to 6 hours and support the battery level displaying.
- Wired controller supports voice calls, volume adjustment and music switching.
- IPX4 grade waterproof can cope with daily movement sweat and splashing water.

■Specification

Bluetooth version: Bluetooth V4.1

Bluetooth protocol: HFP, HSP, A2DP, AVRCP

Connecting distance: 10m

Working time: 6h

Charging time: 2h

Standby time: About 150h

Input: DC 5V ±500mA


Frequency response: 20Hz-20KHz

Sound pressure level(SPL): 100±3dB

Impedance: 16Ω

1


■Box contents



■Function operational

- Volume increase/next track
- Charging port
- LED Indicator
- Multi-function key
- Volume decrease/previous track
- Microphone

1



2

■Operation

1. Charging

Before the first use or the battery is in low level, please complete charging firstly.

1. Plug the USB charging cable into USB port of power source.

2. Connect the charging cable to the headphone's micro USB charging port.

Red light on = Charging Blue light on = Fully charged

Charging time: It takes about 2 hours to do a fully charged.



Fully Charged

low battery level

Tips:

1. When red light quickly flashes instead of blue light and headphone emit prompt per 1 minute, it shows the battery is in low level, and just can supports 30 minutes use.

2. In order to avoid shortening the battery life, please charge the headphone at least per 3 months when the headphone is unuse for a long time.

Warning:

The rechargeable batteries of the headphone must be properly disposed for recycling. Never dispose of batteries in fire to avoid explosion.

II. ON/OFF

Function	Operation	Indicator
ON	Press and hold multi-function button for about 3 seconds	Blue light is on for 1 seconds
OFF	Press and hold multi-function button for about 4 seconds	Red light is on for 1 seconds

Tips

1. Pairing status will keep about 2 minutes, the headphone will return to standby status after 2 minutes without connecting successfully. The headphone will automatically turn off after 10 minutes without any operation.

2. When the headphone is out of connecting distance, it will automatically re-connect if the headphone enters the connecting distance in 5 minutes, and it will automatically turn off if headphone out of the connecting distance over 10 minutes.

III. Pairing

- Make the headphone enter into pairing mode according to the follow operation

Function	Operation	Indicator
Enter into pairing mode	Press and hold multi-function key for about 2 seconds in ON status	Press and hold multi-function key for about 5 seconds in OFF status

2. Keep your mobile and the headphone within 1 meter distance. The closer, the better.

3. Enable Bluetooth function on your mobile and search for Bluetooth devices.

4. Select "EDIFIER W280BT" to pair up and connect. When successfully connected, the blue light of the headphone flashes slowly.

4

Tips:
When under pairing process, PIN code for connection is "0000" if needed. After complete pairing, the headphone will automatically connect the last connected device in the next time use.Connecting with two devices
1. Pair the headphone with the first device.
2. Re-start the headphone and enter pair status. Press and hold the multi-function key for about 5 seconds to enter the pairing settings, and pair with the second device.

3. Select connecting with the headphone from the first device. Now the headphone is connected with the first and second devices.

IV. Making call via headphone

1. Basic operations

Function	Headset status	Operation
Answer call	Incoming a call	Press multi-function key
Reject call	Incoming a call	Press and hold multi-function key for about 2 seconds
End call	Talking	Press multi-function key
Increase volume	Talking	Press + key
Decrease volume	Talking	Press - key
Mute	Talking	Press and hold - key for about 2 seconds
Cancel mute	Talking (muted)	Press and hold + key for about 2 seconds
Transfer call to mobile	Talking (headphone)	Press and hold multi-function key for about 2 seconds
Transfer call to headphones	Talking (headphones)	Press and hold multi-function key for about 2 seconds
Last number redial	Device connected and without call	Press and hold multi-function key for about 2 seconds
Voice assistant	Device connected and without call	Double click multi-function key

5

2. Three party call operation

Function	Headset status	Operation
Answer new incoming call and end the current call	Incoming the second call	Press multi-function key
Answer new incoming call and hold the current call	Incoming the second call	Double press multi-function key
End the current call and switch to the original call	Talking	Double press multi-function key
End the current call and switch to the original call	Talking the second call	Press multi-function key

3. Connect call from two mobiles

Function	Headset status	Operation
End the first mobile call and start the second incoming call	Another call comes in when you are on the first call	Press multi-function key
Put the first mobile on hold to answer the second incoming call	Another call comes in when you are on the first call	Double press multi-function key
Switch call	Talking while one call is on hold	Double click multi-function key
End the current call and return to the on-hold mobile call	Talking while one call is on hold	Press multi-function key

6

V. Restore factory setting
Turn off the headphone and connect to USB port for charging, press and hold multi-function key and volume + key until blue light flashes quickly, then loose the two keys to restore factory setting.

■Maintenance and repair

Please read the following suggestions. These suggestions will help you stay in compliance with the warranty terms and prolong the product life.

- Keep the product dry and away from wet places to avoid moisture getting into internal circuit. Do not use the product during intense exercise or when you sweat too much.
- Do not place the product under directly the sunlight or near heat sources. High temperature will shorten the electronic components' life and damage batteries and cause certain plastic deformation.
- Do not put the product in very cold places in order to prevent its internal circuit board from being damaged.
- Do not dismantle the product. Non-technician may damage the product.
- Do not drop, violently vibrate or strike the product with hard items. It may cause damage to the circuit.
- Do not use strong chemical products or detergent to clean the headphone.
- Do not use sharp items to scratch the product surface. It may damage the housing surface.
- If the product cannot work properly, please send it to your local authorized service stations. The staff will be keen to help you.

7

■FAQs

1. The red light is flashing instead of the blue light. Answer: It means the headphone battery has low power. You need to recharge the headphone.

2. The red light is off when charging.

Answer: a. Please ensure the connection between the charging device and the headphone works well.

b. The batteries would be in the state of hibernation if the headphone is not in use for a long time. It needs to be recharged for about 30 minutes before the red light comes back on.

3. You cannot hear anything from the headphone.

Answer: a. Make sure the headphone's volume is correct.

b. Make sure the headphone is properly connected with your mobile.

c. Make sure if the headphone is not out of the range from your mobile or there is any interfering device nearby.

4. The call quality is not good.

Answer: a. Make sure if your mobile is in the area having strong signal.

b. The effective work range of the headphone is 10 meters. Make sure the headphone is within the effective work range and there are no obstacles between the headphone and your mobile.

5. Why cannot the headphone pause, resume, go fast and next when playing music?

Answer: These functions require paired devices that support AVRCP protocol (Audio/Video Remote Control Profile).

8

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.



- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- Fully understand user manual before use.
- Ensure your player at low volume levels or power off before you leaving.

9

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

10

EN Warning!

To guarantee your personal safety, please do not wear or keep earphones in the vicinity (closer than 10cm) of a pacemaker.

Do not insert plug into electric sockets.

Supervise children when using the equipment, the product is not a toy.

Earphone listening at high volume levels – particularly, over extended periods of time – may damage your hearing.

The operation of switches on your hi-fi system or plugging in the earphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the earphones.

For traffic safety, do not use earphones while driving or cycling.

11

CN 安全注意事项:

為保證您的人身安全, 請勿將該耳機戴或放置在離心臟起搏器過近的位置(小於10CM)。

請勿將插頭插入電源插座。

兒童應在成人監督下使用本設備, 本產品非玩具。

在高音量下使用耳機——特別是長時間使用——可能會對您的聽力造成損傷。

操作高音量者會關閉或插入耳機時可能會發出尖利的聲音, 其在高音量設置下可能會影響您的聽力。因此, 在切換多種音源或插入耳機前, 請將音量控制設置為最低。

為交通安全起見, 騎車或騎自行車時請勿使用耳機。

FR Conseils de Sécurité!

Pour votre sécurité, ne portez pas et ne posez pas ce casque à proximité immédiate (moins de 10 cm) d'un pacemaker.

Ne pas introduire la fiche à Jack dans des prises de courant.

Surveillez vos enfants s'ils utilisent l'appareil. Ce produit n'est pas un jouet.

Un casque d'écoute utilisé à un volume élevé risque de provoquer de troubles de l'audition, en particulier si l'il est porté de façon prolongée.

Lorsque vous procédez à un réglage sur votre installation hi-fi ou que vous branchez le casque sur l'installation, des bruits dangereux pour l'oreille peuvent se produire si le son est réglé sur un volume élevé. Pour cette raison, il faut toujours mettre le son au minimum avant de passer d'une source à l'autre (radio, platine, lecteur de CD ...) ou de brancher le casque.

Pour ne pas mettre en danger votre sécurité au volant ni celle des autres usagers de la route, n'utilisez jamais le casque lorsque vous conduisez ou que vous roulez à vélo.